

# Печи с верхней загрузкой в качестве плавильных печей F

## Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижегород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

**Россия** +7(495)268-04-70

**Казахстан** +(727)345-47-04

**Беларусь** +(375)257-127-884

**Узбекистан** +998(71)205-18-59

**Киргизия** +996(312)96-26-47

эл.почта: [nme@nt-rt.ru](mailto:nme@nt-rt.ru) || сайт: <http://nabertherm.nt-rt.ru/>

# Top Loaders as Fusing Furnaces

Choose the ideal companion for your fusing work – our top loaders as fusing furnaces. With robust refractory insulation and protected heating in the lid, our fusing furnaces in the F 75 – F 220 range with additional side heating provide optimum support.

## Standard equipment

- Refractory insulation ensures clean firing results
- Lid with adjustable quick-release lock and padlock
- Adjustable lid suspension
- Durable lid seal (brick on brick)
- Lid interlock safety switch
- Heating elements in the roof, with fusing furnaces F 75 – F 220 also all around the sides
- Solid state relays ensure low noise heater operation
- Powerful gas struts support lid opening

- Top loader F 30 as tabletop model without castors
- F 220 with two-zone control (lid and side) as standard

## Controller

- Controller with touch operation C540 (10 programs with each 20 segments) or P570 (50 programs with each 40 segments) for F 220; controls description, see page 58

**A reliable companion whose performance will delight you!**

“I entrust my art to my Nabertherm fusing furnace.”

David Perry  
[davidperryglassceramics.uk](http://davidperryglassceramics.uk)

Additional  
equipment  
see page 43



Fusing furnace F 30



Sturdy lid design with two lid brackets



Interior with bottom side ring heating on fusing furnaces F 75 – F 220



Sturdy professional-grade castors on fusing furnaces F 75 – F 220

| Model  | Tmax<br>°C | Inner dimensions in mm |     |     | Floor space<br>in m <sup>2</sup> | Outer dimensions <sup>1</sup> in mm |      |     | Connected load <sup>2</sup><br>kW | Electrical<br>connection* | Weight in<br>kg |
|--------|------------|------------------------|-----|-----|----------------------------------|-------------------------------------|------|-----|-----------------------------------|---------------------------|-----------------|
|        |            | w                      | d   | h   |                                  | W                                   | D    | H   |                                   |                           |                 |
| F 30   | 950        | Ø 410                  |     |     | 0.13                             | 640                                 | 770  | 585 | 2.0                               | 1-phase                   | 55              |
| F 75 L | 950        | 750                    | 520 | 230 | 0.33                             | 945                                 | 930  | 690 | 3.6                               | 1-phase                   | 95              |
| F 75   | 950        | 750                    | 520 | 230 | 0.33                             | 945                                 | 930  | 690 | 5.5                               | 3-phase                   | 95              |
| F 110  | 950        | 930                    | 590 | 230 | 0.47                             | 1130                                | 1000 | 690 | 7.5                               | 3-phase                   | 110             |
| F 220  | 950        | 930                    | 590 | 460 | 0.47                             | 1130                                | 1000 | 920 | 15.0                              | 3-phase                   | 150             |

<sup>1</sup>External dimensions vary when furnace is equipped with additional equipment. Dimensions on request

\*Please see page 62 for more information about supply voltage

<sup>2</sup>The connected load refers to the standard furnace and may increase for a furnace with additional equipment. For furnaces with connection options for multi-range voltages, the connected load applies to the highest permissible connected voltage.



## По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижегород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

**Россия** +7(495)268-04-70

**Казахстан** +(727)345-47-04

**Беларусь** +(375)257-127-884

**Узбекистан** +998(71)205-18-59

**Киргизия** +996(312)96-26-47

эл.почта: [nme@nt-rt.ru](mailto:nme@nt-rt.ru) || сайт: <http://nabertherm.nt-rt.ru/>